MAGNUM® MHC1350-5N6135B3 Gusseted Cap Allowable Capacity 98 Tons Compression / 83 Tons Tension

6" x 13-1/2" x 3/4" Bearing Plate & 5.75-Inch I.D. Collar Fits MH530, MH536, MH542 & MH547 Helical Piles

Description: MAGNUM® Gusseted Plate Caps consist of a collar tube with a bolt holes for connection to MAGNUM® helical piles and a stiffened steel bearing plate. MAGNUM® products are manufactured in the USA according to our ISO 9001 approved quality program. Structural capacities are developed according to AISC 360 considering an average design life of 75 years for bare steel in most soil conditions. Hot-dip galvanizing is available upon request. Design and detailing of the structure, to which bearing plate cap is attached varies by project and is the responsibility of the registered design professional.

| Specifications | |
|-----------------------------------|---|
| Collar Tube | 0.44" x 5.75" I.D. ASTM A252, Fy = 70 ksi or Better |
| End Effecter | 6" x 13-1/2" x 3/4" Steel Bearing Plate with Support Gussets |
| Pile Connection | (3) 1-1/2" SAE J429 Grade 5 Zinc Coated to ASTM B695/F1941 |
| Coating | Galvanized per ASTM A153/A123 (G), Bare Steel (NG), or Epoxy Coated per ICC-ES AC228 (EP) |
| Compatibility | MH530-6, MH536-6, MH542-6, MH547-6 |
| Capacity | |
| Ultimate Compression/ Tension | 195 Tons / 165 Tons |
| Allowable Compression/ Tension | 98 Tons / 83 Tons |

Notes: Cap capacity is developed using the ASD design method and considers strength of collar, end effecter, and pile connection. Capacity may be limited by the helical pile itself, bearing/pullout capacity of soil, or strength of the structure to which the cap is attached.





Installation Notes: After installation of a MAGNUM® Helical Pile to the correct depth, torque, and capacity, cut-off the pile shaft at the proper elevation. Drill (3) 1-9/16" holes through the shaft using a MAGNUM® drill template, place the cap over the shaft and secure with (3) 1-1/2" bolts. Snug tighten nuts. Alternatively, drilling through pile may be omitted and plug welds may be used to secure cap to pile in place of bolt(s), see MAGNUM® Technical Bulletin TB004. Ensure direct bearing of plate on shaft.



156 Circle Freeway Dr. Cincinnati, OH. 45246 800-822-7437 www.MagnumPiering.com